

Oneiro Dream

Smart Glide



Colours available: red, black, cream and brown



Built-in Sound Soothe provides immersive sounds of nature.



DIMENSIONS:

Chair Reclined Dimensions: 188cm L x 86cm W x 81cm H
 Chair Upright Dimensions: 160cm L x 86cm W x 117cm H
 Seat Width: 51cm



★ 5 Years

WARRANTY
Labour & Parts

SHOWROOM LOCATIONS

HEAD OFFICE 292 Port Rd, Hindmarsh SA 5007
SHOWROOM WAREHOUSE Unit 11 / 75 Endeavour Way, SUNSHINE WEST VIC 3020
WESTFIELD SHOPPING CENTRE MARION 297 Diagonal Rd, OAKLANDS PARK SA 5046

Feelgood Massage Chairs Aust Pty Ltd are Australia's most trusted wholesalers of massage chairs with 18 years experience in the industry. Feelgood Massage Chairs are leading suppliers in Australia of commercial and home massage chairs. We have a range of the latest technology in massage chairs to suit everybody. Our comprehensive range of massage chairs are available at competitive prices. Feelgood offers comprehensive technical support for all its massage chairs.

SALE & DELIVERY AUSTRALIA WIDE

Feelgood massage chairs, luxury at an affordable price.

www.feelgoodmassagechairs.com.au

feelgood
massage chairs

Oneiro Dream

3D/4D Massage Chair

Smart Glide

Start Living Your Dream ... Calm Your Mind And Soothe Your Senses



\$7,999
feelgood
massage chairs

★ 5 Years

WARRANTY
Labour & Parts

Oneiro Dream 3D/4D Massage Chair Smart Glide

Oneiro Auto-Wellness Massage Chair Programs

Auto Program details: Tension Relief, Yoga Studio, Performance, Full Body, Upper Body, Lower Body.

Manual Massage Programs details: Knead, Tap Touch, Percussion, Shiatsu, Knead & Percussion, Audio Sync. In all of these modes you can focus massage on your full body, a zone or a particular spot you desire. You can choose the width of massage to suit your upper body size for accurate massage. Speed is also selectable. Indulge in 38 programs, including full-body immersion, deep tissue and an effective collection of therapeutic relaxation and recovery programs.

Cloud Touch Program details: Focus and intensity programs for Full, Arm Shoulder, Back & Waist, Leg & Foot, Hip. Strategically placed targeted air cells apply pressure to key healing points and manipulate your body to stretch muscles.

Three Rollers Under Foot

The reflex zone: Reflexology pressure massage in the toe reflex zone can help eliminate toxins and increase circulation for better health.

The heel reflex zone: Regular foot massage can help to remove toxins and increase healthy blood flow to the rest of the body and improve sleep.

Sole reflex zone: Steady massage here can help improve circulation, stimulate muscles, reduce tension, and often eases pain. Whether you suffer from one of the conditions noted above or you've just had a rough day, a soothing foot massage may be just the key to not only feeling better today but also to leading a healthier, longer life. HEATED FOOT AND CALF MASSAGER with under foot rollers for optimized reflexology and adjustable intensity for knees, calves and feet, the extendable leg rest automatically adjusts for your height.

Dual-lumbar Heat Graphene Heat System

The **Oneiro** is incorporated with enhanced thermal properties to increase blood circulation and help to soften hard muscles. 3 heat settings. **Adjustable and targeted heat gently soothes the back to loosen tight muscles and help relieve pain.**

Arm Rest Quick Control Magnetic Dock And Holder

Manage your devices in a variety of convenient ways.

Power switch, toggle selector, adjusts chair up and down, remote control holder.

Built-in USB Port

Use the built-in USB port to charge your favourite hand-held device while you listen to music, watch videos, or read an eBook.

3D Intelligent Mechanism

3D intelligent mechanism perfectly follows the cervical spine curves. Innovative mechanism crank with built-in spring delivers in-depth massage along the entire length of your spine.

4D Massage, 1300mm Super Long SL Track 3D 8mm, 4D 9mm In-depth Massage

An intelligent precise massage mechanism can flex up to 8mm automatically imitating a human massage. 4D massage chair delivers an elevated level of deep tissue massage above and beyond what is expected. The 4D mechanism is versatile for many users because of its ability to increase or decrease how much pressure is applied to the muscles. This advanced 4D movement provides a more life like, precise and natural massage experience to the user. The ultimate 1300mm SL super long massage track technology delivers 4D massage along the entire spine all the way done to your glutes. It covers 60% more of the back than conventional chairs.

Zero Gravity Position Massage

Developed by NASA scientists, the Zero Gravity technology has been incorporated into the **Oneiro** massage chair design. The weight of your body can be evenly distributed throughout, reducing the pressure on the spine and joints.

One Press Control Sliding Forward

The chair will slide forward by 28cm and recline afterwards. Allow 10cm wall clearance behind the chair to ensure enough room for the chair to recline.

Colours available

Black, ivory, red, brown

Double Acting Footrest/ Auto Extend Footrest

Under foot sensor can detect the foot location of various heights between 150 -190cm. It follows the contour of the users feet to deliver a complete reflexology stress-relieving massage. Upper footrest can stretch by 90mm in both directions, lower footrest can stretch by 160mm in both directions. Features the auto glide knee setting adjustable up and down motion reflexology massage.



4D MASSAGE PROGRAMS



While 2D massage programs massage vertically and horizontally, and 3D programs add depth, **4D programs** take massage one step further to include the dimension of **variable speed**. Massage strokes speed up and slow down mid-stroke, just like the hands of a professional massage therapist, for the most realistic massage yet!



ADVANCED FINGERTIP CONTROLS

Easily manage the chair's key functions at your fingertips using the convenient control panel.

- Power On
- Start the Default Auto Program
- Adjust Recline Position
- Heat On/Off
- Volume Control
- Restore the Chair to Full Upright Position



USING THE REMOTE CONTROL

The status screen displays during your massage, providing a quick reference for the following information. This handy display not only shows the current status for each of the settings, but allows you to configure the settings in the upper left-hand corner of the screen. Use the up/down navigation buttons to toggle through the settings; use the right/left buttons to adjust them.

KND SPEED— In manual mode, the Kneading, Tap Touch, Percussion, or Knead & Percuss speed

CLOUD TCH— The Cloud Touch intensity (Cloud Touch must be active to set the intensity)

FOOT SPD—The underfoot roller speed (rollers must be on to set the speed)

WIDTH—In manual mode, the Tap Touch, Percussion, or Shiatsu horizontal massage range

3D— The back massage intensity (not configurable during Meditation programs)

The amount of time remaining in the current massage session

Illustrates the areas currently being massaged

The active massage program

Lights blue when Bluetooth is set to On

Lights blue when chair is in ZeroG position

The active robotic massage technique

Vertical massage range indicator:

- Full
- Zone
- Spot

Lights red if heat is on

MENU — Displays the main menu. Press twice fast to go back a screen.

AUTO — Displays the AUTO programs menu. When an auto program is running, press to toggle among the auto programs. The active program displays at the top of the status screen.

CLOUD — When the status screen is displayed, press to adjust the Cloud Touch intensity. The selected intensity displays in the upper left-hand corner of the screen.

BACK — Press and hold to recline or incline the backrest.

LEGGS EXTEND— Press and hold to extend the footrest.

NOTE: During auto programs, your leg length is automatically measured and the program adjusted accordingly.

ON/OFF — Press this button:

- To power on the remote.
- Select STOP to stop your massage immediately.
- Select POWER OFF, then select RESTORE to return the chair to the upright position before exiting.

Press the up/down/left/right buttons to navigate the screens; press the center button to select an option.

POSITION — Use to move the massage rollers to the desired position when enjoying a Zone or Spot massage. See **Using Manual Massage Modes** on page 16 for more information.

HEAT — Press to toggle the backrest and footrest heat on and off.

LEGGS — Press and hold to raise or lower the footrest.

ZeroG— Press and hold to automatically position the chair in ZeroG mode, raising your feet above your heart for maximum spine relief.

LEGGS RETRACT— Press and hold to retract the footrest.

Ⓞ If the chair is not in use for three minutes the controller display automatically shuts down. Press the **ON/OFF** button to resume use. The chair resets all settings to the default position.